

Not to scale

 Up to date stocking status can be viewed at www.lidco.com.au/indices
00-057SC – Sash Lift Handle (satin chrome)

For 424 and 748 Systems



00-058 – Latch (Double Hung)

00-058-92607 – Latch (Double Hung)

00-058-92609 – Latch (Double Hung)

00-060 – Keeper (Double Hung)

For 424 and 748 Systems


00-535 – Screen Catch

02-014 – 3mm Woolpile

02-015 – 4mm Woolpile

02-019 – Fin Seal 48 T Slot 4.25mm

02-040 – 4mm Q-Lon


DESIGNER RANGE 424 SYSTEM

Thermaview™ Double Hung Window



Up to date stocking status can be viewed at www.lidco.com.au/indices

Not to scale

02-082 – Bulb Seal (PVC)



02-153 – V Seal (Mullion)

Suitable for COM-020, COM-041,
700-646, 400-314



03-059 – Alignment Spring

For 424 and 748 Systems



03-134 – Sash Stop (Bottom)



03-135 – Sash Stop (Top)



04-065 – 6mm Glazing Channel



04-067 – 5mm Glazing Channel



04-209 – 10mm Glazing Channel




04-217 – 8mm Glazing Channel




04-333 – 18mm Glazing Channel




Not to scale

 Up to date stocking status can be viewed at www.lidco.com.au/indices
04-545 – 4mm Glazing Channel

05-504 – Gasket (65mm D/Hung Head)



For 424 System


05-505 – Gasket (65mm D/Hung Sill)

For 424 System


05-673 – Corner Stake


Suitable for 400-673


06-136 – Balance Tube Screw

06-672 – Friction Foot (424/748)

09-266 – Offset Clip (Stainless Steel)

09-271 – Turn Button Long (Black)

09-276 – Bow Spring (Flat Form)

09-278 – Flexible Handle (black)


DESIGNER RANGE 424 SYSTEM

Thermaview™ Double Hung Window




Up to date stocking status can be viewed at www.lidco.com.au/indices

Not to scale

09-537 – Screen Clip (Double Hung)



09-538 – Head Clip (Double Hung)




Not to scale

Up to date stocking status can be viewed at www.lidco.com.au/indices

Spiral Balance Guide

Spiral Balance Selection Table		
Part Number	Body Length	Weight
06-500-01	318	2.25 – 7.25kg
06-500-02	343	2.25 – 7.25kg
06-500-03	368	2.25 – 7.25kg
06-500-04	394	2.25 – 7.25kg
06-500-05	419	2.25 – 7.25kg
06-500-06	445	2.25 – 7.25kg
06-500-07	470	2.25 – 7.25kg
06-500-08	495	2.25 – 7.25kg
06-500-09	521	2.25 – 7.25kg
06-500-10	546	2.25 – 7.25kg
06-500-11	572	2.25 – 7.25kg
06-500-12	597	2.25 – 7.25kg
06-500-13	622	2.25 – 7.25kg
06-500-14	648	7.25kg – 10kg
06-500-15	673	7.25kg – 10kg
06-500-16	699	7.25kg – 10kg
06-500-17	724	7.25kg – 10kg
06-500-18	749	7.25kg – 10kg
06-500-19	775	7.25kg – 10kg
06-500-20	800	7.25kg – 10kg
06-500-21	826	7.25kg – 10kg
06-500-22	851	7.25kg – 10kg
06-500-23	876	10kg – 14kg
06-500-24	902	10kg – 14kg
06-500-25	927	10kg – 14kg
06-500-26	953	10kg – 14kg
06-500-27	978	10kg – 14kg
06-500-28	1003	10kg – 14kg
06-500-29	1029	10kg – 14kg

Suitable for Lidco double hung windows



Up to date stocking status can be viewed at www.lidco.com.au/indices


Not to scale

Spring Balance Selection Guide

Each double hung window requires **FOUR** Spring Feet and **ONE** Spring Balance Kit.

Spring Balance Kit includes:

- 4 x Springs
- 4 x Tubes
- 4 x Stops
- 4 x End Caps



Spring Balance Selection Chart – 4mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	599	06-600-001	06-600-001	06-600-001	06-600-001	06-600-002	06-600-002	06-600-002	06-600-002	06-600-002	06-600-003
	699	06-600-008	06-600-008	06-600-009	06-600-009	06-600-009	06-600-009	06-600-009	06-600-010	06-600-010	06-600-010
	799	06-600-015	06-600-016	06-600-016	06-600-016	06-600-016	06-600-017	06-600-017	06-600-017	06-600-017	06-600-018
	899	06-600-022	06-600-023	06-600-023	06-600-023	06-600-024	06-600-024	06-600-024	06-600-024	06-600-025	06-600-025
	999	06-600-030	06-600-030	06-600-030	06-600-031	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032
	1099	06-600-037	06-600-037	06-600-038	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039
	1199	06-600-044	06-600-044	06-600-045	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046
	1299	06-600-051	06-600-052	06-600-052	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053
	1399	06-600-058	06-600-059	06-600-059	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061
	1499	06-600-066	06-600-066	06-600-067	06-600-067	06-600-067	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068
	1599	06-600-073	06-600-073	06-600-074	06-600-074	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075
	1699	06-600-080	06-600-080	06-600-081	06-600-081	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-082
	1799	06-600-087	06-600-088	06-600-088	06-600-088	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-089
	1899	06-600-094	06-600-095	06-600-095	06-600-095	06-600-095	06-600-096	06-600-096	06-600-096	06-600-096	06-600-097
	1999	06-600-102	06-600-102	06-600-102	06-600-102	06-600-103	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104
	2099	06-600-109	06-600-109	06-600-109	06-600-109	06-600-110	06-600-110	06-600-110	06-600-110	06-600-111	06-600-111
	2199	06-600-116	06-600-116	06-600-116	06-600-116	06-600-117	06-600-117	06-600-117	06-600-118	06-600-118	06-600-118
2299	06-600-123	06-600-123	06-600-123	06-600-124	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-125	

Not to scale

Up to date stocking status can be viewed at www.lidco.com.au/indices

Spring Balance Selection Guide

Spring Balance Selection Chart – 5mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	599	06-600-001	06-600-001	06-600-002	06-600-002	06-600-002	06-600-002	06-600-003	06-600-003	06-600-003	06-600-003
	699	06-600-008	06-600-009	06-600-009	06-600-009	06-600-010	06-600-010	06-600-010	06-600-010	06-600-011	06-600-011
	799	06-600-016	06-600-016	06-600-016	06-600-017	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018
	899	06-600-023	06-600-023	06-600-024	06-600-024	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025
	999	06-600-030	06-600-031	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032
	1099	06-600-037	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040
	1199	06-600-045	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047
	1299	06-600-052	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054
	1399	06-600-059	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061	06-600-061	06-600-061	06-600-061
	1499	06-600-066	06-600-067	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068	06-600-068	06-600-068	06-600-069
	1599	06-600-074	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075	06-600-075	06-600-076	06-600-076
	1699	06-600-081	06-600-081	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083
	1799	06-600-088	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-089	06-600-090	06-600-090	06-600-090
	1899	06-600-095	06-600-095	06-600-095	06-600-096	06-600-096	06-600-096	06-600-097	06-600-097	06-600-097	06-600-097
	1999	06-600-102	06-600-102	06-600-103	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104	06-600-104	06-600-105
	2099	06-600-109	06-600-109	06-600-110	06-600-110	06-600-110	06-600-111	06-600-111	06-600-111	06-600-112	06-600-112
	2199	06-600-116	06-600-116	06-600-117	06-600-117	06-600-117	06-600-118	06-600-118	06-600-118	06-600-119	06-600-119
2299	06-600-123	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-125	06-600-126	06-600-126	06-600-126	

Spring Balance Selection Chart – 6mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	599	06-600-001	06-600-002	06-600-002	06-600-002	06-600-003	06-600-003	06-600-003	06-600-003	06-600-004	06-600-004
	699	06-600-009	06-600-009	06-600-009	06-600-010	06-600-010	06-600-010	06-600-011	06-600-011	06-600-011	06-600-011
	799	06-600-016	06-600-016	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018
	899	06-600-023	06-600-024	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-026
	999	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-033	06-600-033
	1099	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040
	1199	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047	06-600-047	06-600-047
	1299	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054	06-600-054	06-600-055
	1399	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061	06-600-061	06-600-061	06-600-061	06-600-062	06-600-062
	1499	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068	06-600-068	06-600-068	06-600-069	06-600-069	06-600-069
	1599	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075	06-600-076	06-600-076	06-600-076	06-600-077
	1699	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083	06-600-083	06-600-083	06-600-084
	1799	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-090	06-600-090	06-600-090	06-600-091	06-600-091
	1899	06-600-095	06-600-096	06-600-096	06-600-096	06-600-097	06-600-097	06-600-097	06-600-098	06-600-098	06-600-098
	1999	06-600-102	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104	06-600-105	06-600-105	06-600-105	-
	2099	06-600-109	06-600-110	06-600-110	06-600-111	06-600-111	06-600-111	06-600-112	06-600-112	06-600-112	-
	2199	06-600-116	06-600-117	06-600-117	06-600-118	06-600-118	06-600-119	06-600-119	06-600-119	-	-
2299	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-126	06-600-126	06-600-126	-	-	

Up to date stocking status can be viewed at www.lidco.com.au/indices

Not to scale

Spring Balance Selection Guide

Spring Balance Selection Chart – 8mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	599	06-600-002	06-600-002	06-600-003	06-600-003	06-600-004	06-600-004	06-600-004	06-600-004	06-600-004	06-600-004
	699	06-600-009	06-600-010	06-600-010	06-600-011	06-600-011	06-600-011	06-600-011	06-600-011	06-600-011	06-600-012
	799	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018	06-600-019	06-600-019	06-600-019
	899	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-026	06-600-026	06-600-026	06-600-026
	999	06-600-032	06-600-032	06-600-032	06-600-032	06-600-033	06-600-033	06-600-033	06-600-033	06-600-034	06-600-034
	1099	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040	06-600-041	06-600-041	06-600-041
	1199	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047	06-600-047	06-600-048	06-600-048	06-600-048	06-600-049
	1299	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054	06-600-055	06-600-055	06-600-055	06-600-056	06-600-056
	1399	06-600-060	06-600-060	06-600-061	06-600-061	06-600-062	06-600-062	06-600-062	06-600-063	06-600-063	06-600-063
	1499	06-600-067	06-600-068	06-600-068	06-600-068	06-600-069	06-600-069	06-600-070	06-600-070	06-600-070	-
	1599	06-600-074	06-600-075	06-600-075	06-600-076	06-600-076	06-600-076	06-600-077	06-600-077	06-600-077	-
	1699	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083	06-600-084	06-600-084	06-600-084	-	-
	1799	06-600-089	06-600-089	06-600-090	06-600-090	06-600-091	06-600-091	06-600-091	-	-	-
	1899	06-600-096	06-600-096	06-600-097	06-600-097	06-600-098	06-600-098	-	-	-	-
	1999	06-600-103	06-600-104	06-600-104	06-600-105	06-600-105	06-600-105	-	-	-	-
	2099	06-600-110	06-600-111	06-600-111	06-600-112	06-600-112	-	-	-	-	-
	2199	06-600-117	06-600-118	06-600-118	06-600-119	06-600-119	-	-	-	-	-
2299	06-600-124	06-600-125	06-600-126	06-600-126	-	-	-	-	-	-	

Spring Balance Selection Chart – 10mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	599	06-600-003	06-600-003	06-600-004	06-600-004	06-600-004	06-600-004	06-600-004	06-600-004	06-600-005	06-600-005
	699	06-600-010	06-600-011	06-600-011	06-600-011	06-600-011	06-600-011	06-600-012	06-600-012	06-600-012	06-600-012
	799	06-600-018	06-600-018	06-600-018	06-600-018	06-600-019	06-600-019	06-600-019	06-600-019	06-600-020	06-600-020
	899	06-600-025	06-600-025	06-600-025	06-600-026	06-600-026	06-600-026	06-600-026	06-600-027	06-600-027	06-600-027
	999	06-600-032	06-600-032	06-600-033	06-600-033	06-600-033	06-600-033	06-600-034	06-600-034	06-600-034	06-600-035
	1099	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040	06-600-041	06-600-041	06-600-041	06-600-042	06-600-042
	1199	06-600-046	06-600-047	06-600-047	06-600-047	06-600-048	06-600-048	06-600-049	06-600-049	06-600-049	-
	1299	06-600-053	06-600-054	06-600-054	06-600-055	06-600-055	06-600-055	06-600-056	06-600-056	-	-
	1399	06-600-061	06-600-061	06-600-062	06-600-062	06-600-062	06-600-063	06-600-063	-	-	-
	1499	06-600-068	06-600-068	06-600-069	06-600-069	06-600-070	06-600-070	-	-	-	-
	1599	06-600-075	06-600-076	06-600-076	06-600-077	06-600-077	06-600-077	-	-	-	-
	1699	06-600-082	06-600-083	06-600-083	06-600-084	06-600-084	-	-	-	-	-
	1799	06-600-089	06-600-090	06-600-091	06-600-091	-	-	-	-	-	-
	1899	06-600-097	06-600-097	06-600-098	06-600-098	-	-	-	-	-	-
	1999	06-600-104	06-600-104	06-600-105	-	-	-	-	-	-	-
	2099	06-600-111	06-600-112	06-600-112	-	-	-	-	-	-	-
	2199	06-600-118	06-600-119	06-600-119	-	-	-	-	-	-	-
2299	06-600-125	06-600-126	-	-	-	-	-	-	-	-	

Not to scale

Up to date stocking status can be viewed at www.lidco.com.au/indices

THERMAVIEW™ DOUBLE HUNG WINDOW – 424 SYSTEM – HARDWARE SUMMARY

Item No	Description	Colour	Material
00-057SC	Sash Lift Handle	satin chrome	
00-058	Latch	black	
00-058-92607	Keyed Latch	black	
00-058-92609	Keyed Latch	black	
00-060	Keeper		stainless steel
00-535	Screen Catch	black	plastic
02-014	3mm Woolpile	black	
02-015	4mm Woolpile	black	
02-019	4.25mm Finseal	black	
02-040	4mm Q-Lon Seal	black	
02-082	Bulb Seal	black	PVC
02-153	V Seal – Mullion	black	PVC
03-059	Bow Spring		
03-134	Sash Stop – Bottom	black	plastic
03-135	Sash Stop – Top	black	plastic
04-065	Glazing Channel – 6mm	black	PVC
04-067	Glazing Channel – 5mm	black	PVC
04-209	Glazing Channel – 10mm	black	PVC
04-217	Glazing Channel – 8mm	black	PVC
04-333	Glazing Channel – 18mm	black	PVC
04-545	Glazing Channel – 4mm	black	PVC
05-504	Gasket – Head		foam
05-505	Gasket – Sill		foam
05-673	Corner Stake	black	plastic
06-136	Male/Female Balance Tube Screw		
06-672	Spring Balance Foot	black	
09-266	Offset Clip		stainless steel
09-271	Turn Button Long	black	plastic
09-276	Bow Spring Flat		
09-278	Flexible Handle	black	plastic
09-537	Screen Clip	black	plastic
09-538	Screen Head Clip	black	plastic